

# H4032



## GoSmart Home Wireless Battery Video Doorbell IP-15S with Wi-Fi

---



### Table of Contents

Safety instructions and warnings .....	2
Contents of the package .....	3
Technical Specifications .....	4
Description of the device .....	5
Installation and assembly .....	6
Pairing with an app .....	7
Controls and functions .....	11
Troubleshooting FAQ .....	12

## Safety instructions and warnings



Before using the device, read the instructions for use.



Observe the safety instructions in this manual.



Do not dispose of electrical appliances as unsorted municipal waste, use sorted waste collection points. Contact your local authority for up-to-date information on collection points. If electrical appliances are disposed of in landfill sites, hazardous substances can leach into groundwater and enter the food chain and harm your health.

EMOS spol. s r.o. declares that the product H4032 complies with the essential requirements and other relevant provisions of the directives. The device can be operated freely in the EU.

The Declaration of Conformity can be found on the website <http://www.emos.eu/download>.

The equipment can be operated on the basis of general authorisation No. VO-R/10/07.2021-8 as amended.

**Package**  
contents Wi-Fi  
doorbell Wireless  
doorbell Holder  
Screws  
Screwdriver  
RESET pin  
Power adapter  
USB cable  
3× AA LR6 1.5 V  
Manual





## Technical Specifications

### Wi-Fi doorbell:

Power supply: DC 5 V/1 A

Dimensions: 140 × 55 × 40 mm

Net weight: 200 g

Resolution: 1 920 × 1 080

Sensor: 1/2.9" 2 Megapixel CMOS

Battery capacity: 5 200 mAh

PIR detection range: 5 m

PIR angle: 100°

Lens: 3.2 mm, F2.0

Storage: SD card (Max. 128 GB), Cloud storage

Degree of protection: IP65

APP: EMOS GoSmart for Android and iOS

Connectivity: 2.4 GHz Wi-Fi


(IEEE802.11b/g/n) Maximum number of users: 4

### Wireless doorbell:

Power: 3 × AA (LR6) 1.5 V

Frequency: 433.92 MHz ±250 kHz Distance: approx. 80 m (open space)

## Notice




The camera only supports 2.4GHz Wi-Fi (does not support 5GHz).



## Description of the device

### Description of the outdoor unit

- 1 - Light sensor
- 2 - Lens
- 3 - PIR sensor (motion sensor)
- 4 - Microphone
- 5 - Status LED:
  - Slowly flashing red light: waiting for network connection
  - Rapidly flashing red light: connecting to the mains
  - Permanent blue light on: the camera is working properly
  - Steady red light on: reporting a fault
- 6 - Ringtone button
- 7 - Speaker
- 8 - Micro USB input
- 9 - RESET button
- 10 - SD card slot
- 11 - On/Off button



### Wireless doorbell description

- 1 - LED status light
  - Flashing red light: ready to pair
  - Flashing blue light: ringing
- 2 - Speaker
- 3 - Volume
- 4 - Melodies
- 5 - Pairing button
- 6 - Micro-USB

## Installation and assembly

### Installing the camera on the wall



1. Attach the bracket to the wall using the mounting screws.
2. Install the camera into the mount and secure it with the screw.

### Pairing a wireless doorbell with a Wifi doorbell

1. Press the button "⚙️" for 2 seconds, the status LED flashes slowly in red and the doorbell is in pairing mode.
2. Then press the ringer button on the Wi-Fi doorbell when the status LED goes off and the melody automatically plays - the pairing was successful.

### Unpair the wireless doorbell with the Wi-Fi doorbell:

1. Press the button "⚙️" for 5 seconds
2. The device switches to factory settings




## Pairing with an app

### Installing the EMOS GoSmart app




- The app is available for Android and iOS via Google play and the App Store.
- Please scan the QR code to download the app.

### EMOS GoSmart mobile app



Open the EMOS GoSmart app and confirm the privacy policy and click I agree. Select the registration option.

Enter the name of a valid email address and choose a password. Confirm your consent to the privacy policy. Select register.





Select Add device.

Select the GoSmart product category and select the Video Doorbell IP-155.



Reset the device using the RESET button on the back of the camera and continue with the application.



Enter the name and password of your Wi-Fi network. This information remains encrypted and is used to allow the camera to communicate with your mobile device remotely.

A QR code will appear on the display of your mobile device. Place the QR code in front of the camera lens.


Confirm that you have heard the beep for a successful pairing. The device is automatically found.

The device is paired and ready for use.




## Icons and indicator lights

### Description of controls in the application




	Advanced settings (described in more detail in the following section)
	Video quality switching (HD/SD)
98%   48 KB/S	Signal quality and speed
	Mute
	Zoom in
	Full screen mode
	Take pictures using the app and save them to your mobile album
	Speak
	Take a video using the app and save it to your mobile album
	Expand menu
	To play a video stored on an SD card
	See videos and photos taken by the app
	Light mode / dark mode
	Night mode settings. We recommend setting to AUTO.
	Motion sensor settings
	Unlocking/locking the lock
	Edit icons + add control of another device
	Message display (Motion detection...)


## Description of extension



- Device information - Basic information about the device and its owner
- Tap-to-Run and Automation - View scenes and automations assigned to the device. Creation of scenes is possible directly in the main menu of the application in the section "Scenes". For the H4032, this could be for example an automation in which motion detection would be activated between 18:00 and 7:00.
- Basic Function Settings - Enable/disable basic control functions such as automatic screen rotation or watermarking with time and date display. Another important setting is the ability to select one-way or two-way communication.
- IR Night Vision - Setting the IR illumination of the device. The same function manages the night mode settings in the device's main panel.
- Detection Alarm Settings - Alarm settings.
- Activity Area - Set the zone in which the camera captures motion. For example, if your camera is sensing a road you don't want the camera to alert you to every car that passes, so this feature allows you to select the area that will be sensed by the motion sensor.



- Human Body Filtering - Human Body Contour Recognition. When you turn this feature on, the device should not alert you to every movement, but only when it recognizes the human body.
- PIR Set - Turning on/off the motion sensor and setting its sensitivity.
- Power Management Settings - Displays the current battery status, power source, and turns on notifications if the battery drops below a specified percentage.
- Bell Settings - Configure the wireless doorbell. The application will request this configuration when pairing the device. Select "Chime Type - Wireless" for proper function.



- Cloud Storage - Cloud storage settings. The cloud is not included in the box, but can be purchased additionally through the app.
- Offline Notification - To avoid constant reminders, a notification will be sent if the device remains offline for more than 30 minutes.
- FAQ & Feedback - View the most common questions along with their solutions plus the ability to send a question/suggestion/feedback directly to us
- Share Device - Share device management to another user
- Add to Home Screen - Add an icon to your phone's home screen. With this step, you don't have to open your device through the app each time, but just click directly on this added icon and it will take you straight to the camera view
- Device update - Device update. Option to enable automatic updates
- Remove Device - Remove and evaporate the device. An important step if you wish to change the owner of the device. After adding the device to the app, the device is paired and cannot be added under another account.

## Controls and functions

### Recording to SD card

One of the basic functions of the home security system is the SD card recording function.

The camera is battery powered, so to save battery and SD card space, it does not record continuously, but only a few seconds of footage once the PIR sensor detects motion.

The camera supports SD cards with a maximum size of 128 GB in FAT32 format. However, 32 GB SD cards are sufficient. When the SD card is full, the recordings are automatically overwritten.



## Troubleshooting FAQ

I can't get the devices to pair. What can I do?

- Make sure you are using a 2.4GHz Wi-Fi network and have a strong enough signal
- Allow the app all permissions in the settings
- Make sure you are using the latest version of the mobile operating system and the latest version of the app

They can hear me outside, but I can't hear the sound outside / I can hear the sound outside, but they can't hear me.



- Make sure you have granted all permissions to the app, especially for the microphone.
- One-way communication can also be a problem. If you see this icon at the bottom: , it means that the device is set to one-way communication.
- To correct this, go to the "Basic Function Settings" menu and set "Talk mode" to "Two-way talk". This menu can be found in the extension settings (see chapter "Description of extension settings").
- The correct icon for two-way communication looks like this: 

I'm not getting notifications, why?

- Allow the app all permissions in the settings
- Turn on notifications in the app settings (Settings -> App notifications)

What SD-Card can I use?

- SD card with a maximum storage capacity of 128 GB and a minimum speed class of CLASS 10 in FAT32 format.

When the SD card memory is full, are the oldest records automatically overwritten or does the user have to manually delete them?

- Yes, the records are overwritten automatically.

Who all can use the equipment?

- Facilities must always have an admin (owner)
- Admin can share the equipment with the remaining household members and assign them rights